
Meridian 1

ISDN Basic Rate Interface

Administration

Document Number: 553-3901-300
Document Release: Standard 5.00
Date: October 1997

© 1992, 1997
All rights reserved

Printed in Canada

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Revision history

October 1997

Issue 5.00 released as Standard for Generic X11 Release 23.

August 1996

Issue 4.00 released as Standard for Generic X11 Release 22.0x.

December 1995

Issue 3.00 released as Standard for Generic X11 Release 21.1x.

July 1995

Issue 2.00 released as Standard for Generic X11 Release 21.0x.

December 1994

Issue 1.00 released as Standard for Generic X11 Release 20.

July 1994

Standard version released for Generic X11 Release 20.0x.

July 1993

Standard version released.

Contents

About this guide	1
Applicability of this guide	1
How this guide is organized	1
Related documents	2
 ISDN BRI implementation	 3
Introduction	3
Configuring ISDN BRI line application	5
Configuration order for line application	5
Configuring pad tables (optional)	6
Configuring an LAPD protocol group for line	9
Removing an LAPD protocol group for a line	10
Printing an LAPD protocol group for a line	10
Configuring a MISP for a line	11
Removing a MISP configured for a line	12
Printing a MISP configured for a line	12
Configuring a BRSC for a line	13
Removing a BRSC configured for a line	17
Printing a BRSC configured for a line	18
Configuring a SILC or UILC for a line	19
Removing a SILC or UILC configured for a line	20
Printing a SILC or UILC configured for a line	20
Configuring a DSL for a line	21
Removing a DSL configured for a line	25
Printing a DSL configured for a line	26
Configuring a TSP for a line	27

Removing a TSP configured for a line	31
Printing a TSP configured for a line	32
Initializing ISDN BRI terminals	33
Initializing a Northern Telecom M5000TD-1 terminal adapter ...	44
Configuring packet data	47
Adding an external packet handler	47
Configuring a MISP for an external packet handler	54
Adding an MPH	82
Configuring ISDN BRI trunk access	139
Configuration order for ISDN BRI trunk access	139
Defining a customer for a trunk	140
Configuring pad tables for a trunk (optional).	141
Configuring an LAPD a protocol group for a trunk	144
Removing an LAPD protocol group for a trunk	145
Printing a protocol group for a trunk	145
Configuring ISDN BRI trunk route data block parameters	146
Configuring a MISP for a trunk	155
Removing a MISP configured for a trunk	157
Printing a MISP configured for a trunk	157
Configuring a SILC or UILC for a trunk	158
Removing a SILC or UILC configured for a trunk	159
Printing a SILC or UILC configured for a trunk	159
Configuring a DSL for a trunk	160
Removing a DSL configured for a trunk	164
Printing a DSL configured for a trunk	164
Configuring trunk clock reference source	165
Configuration procedures for ISDN BRI features	167
Configuring ISDN BRI National ISDN-1 Conference	168
Configuring ISDN BRI ETSI Call Forwarding Unconditional ...	170
Configuring ISDN BRI ETSI Conference	172
Configuring ISDN BRI National ISDN-1 Call Forward All Calls .	173
Configuring ISDN BRI Connected Line Presentation/Restriction .	175
Configuring NI-1 BRI Compliance Enhancements	177
Sample configurations	179
Example one: configuring a line application	179

Configuration procedures	181
Example two: adding an MPH	191
Configuration procedures	192
Example three: Configuring an ISDN BRI Tie trunk	207
Configuration procedures	208
Setting up ISDN BRI traffic reports	215
Selecting the report types	216
Scheduled reporting	217
Immediate reporting	219
ISDN BRI traffic reports	220
Network traffic report (TFS001)	220
MISP/BRSC traffic report (TFS011)	222
MISP/BRSC D-channel management messages report (TFS012) .	224
MISP/BRSC messages report (TFS013)	226
ISDN BRI trunk DSL system traffic report (TFS014)	227
Meridian 1 Packet Handler traffic report (TFS015)	228
Call Detail Recording for the Meridian 1 Packet Handler	230